

Omera 
LPG

**SAFETY
GUIDELINE**



THINGS TO CHECK BEFORE BUYING LP GAS CYLINDER

Thermo Sleeve is rightly attached



Safety cap is rightly attached

STORING AND PLACEMENT OF LP GAS CYLINDER



Always keep the cylinder in an Upright Position



Do not keep the cylinder inside the Kitchen Cabinet or in any Closed Space



If the cylinder is not fitted with a regulator, then always fit the Safety Cap



Place the Gas Cylinder at least 3 feet away from the Stove



Turn off the regulator switch after cooking

THINGS TO DO IF YOU SMELL THE GAS



Open kitchen doors and windows to release gas safely



Immediately switch off the stove



Detach the regulator from the cylinder after turning it off using the knob



Attach the safety cap with the cylinder valve



Turn off the main electric switch in the house

THINGS TO DO IF THERE IS A POSSIBILITY OF ACCIDENT

- Keep the cylinder at a safe distance
- Contact your distributor retailer, our hotline number, or nearest fire service department for assistance.

THINGS TO DO IF GAS LEAKAGE HAPPENS



Turn off all types of electrical devices and lights.



If there's an accident, use a fire extinguisher



Call Fire Service
101, 16163



***NEVER TEST LEAKAGE WITH FIRE
RATHER TEST WITH SOAP***

GENERAL GUIDELINES

- Use certified rubber tubes recommended by Omera or related organizations for LP Gas.
- Check for leaks in rubber tubes/hose pipes using soap water.
- Replace the rubber tube every 2 years with a certified one for your LPG cylinder.
- Contact the nearest authorized Omera dealer or expert technician for any stove or cylinder problems.

 **HOTLINE**
16797